

PLEASE NOTE: All Norman motorised products are pre-programmed at the factory, prior to being shipped out. Please do not perform any of the below functions until you have powered the motor up and tested the product operation.

Wake the Motor (New Installation)

1. Press and hold the motor button for 3 seconds, the light will blink blue and the motor will chime twice to indicate it is operational.

Pairing the Shades to a Channel

1. Press the shade button 3 times.
 - a. The LED light will then blink green, while the shade is ready for pairing.
2. Press and hold the SET button for 3 seconds
3. The LED light will then blink green indicating that the remote is in SETUP mode.
4. Choose a desired channel (1-5) and the selected channel will light up.
5. Press and hold the SET button on the Remote for 3 seconds and the centre buttons will stop blinking which indicates the remote is no longer in SETUP mode.

Set the Upper Limit (Fully Open)

1. Stack all fabric vanes aside to the fully-opened position.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the (▲) open button to save upper limit.

Set the Lower Limit (Fully Closed)

1. Move the shade to the desired position. Fully extend the vanes of the SmartDrape and turn them into the closed position (privacy).
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the (▼) open button to save lower limit.

Setting the Special Limit (Vanes Open)

1. Expand all the fabric vanes and ensure they are in the fully opened position, at 90 degrees.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking - the remote is now in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the SET button to save the special position, with vanes fully open.



Wake the Motor (New Installation)

1. Press and hold the motor button for 3 seconds, the light will blink blue and the motor will chime twice to indicate it is operational.

Pairing the Shades to a Channel

1. Press the shade button 3 times.
 - a. The LED light will then blink green, while the shade is ready for pairing.
2. Remove the remote back cover to reveal the SET button. Press and hold the SET button for 3 seconds.
3. The LED light will then blink green indicating that the remote is in SETUP mode.
4. Press the channel (1-5) for the motor to be added to.
5. Press and hold the SET button on the Remote for 3 seconds and the channel buttons will stop blinking which indicates the remote is no longer in SETUP mode.

Set the Upper Limit (Fully Open)

1. Move all the vanes while in the full opened position to the stacking side/s of the track.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The channel buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade and the selected channel will flash.
4. Press the OPEN (▲) button to save the upper limit.

Set the Lower Limit (Fully Closed)

1. Fully extend the vanes of the SmartDrape and then turn them into the closed position (Privacy).
2. Using a pin (not provided), press and hold the RESET button for 1 second. The channel buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade and the selected channel will start to flash.
4. Press the CLOSE (▼) button to save the lower limit.

Setting the Special Limit (Vanes Open)

1. Expand all the fabric vanes and ensure they are in the fully opened position, at 90 degrees.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The channel buttons will start blinking - the remote is now in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the SET button to save the special position, with vanes fully open.

