

PLEASE NOTE: All Norman motorised products are pre-programmed at the factory, prior to being shipped out. Please do not perform any of the below functions until you have powered the motor up and tested the product operation.

Wake the Motor (New Installation)

1. Press and hold the shade button for 3 seconds.
 - a. The light will blink green to indicate that the motor is now awake.
 - b. The light will blink red to indicate that the motor is now asleep.

Pairing the Shades to a Channel

1. Press the shade button 3 times. The green light will start blinking while the shade is ready for pairing.
2. Press and hold the SET button for 3 seconds
 - a. The LED light will then blink green indicating that the remote is in SETUP mode.
3. Press the Channel (1-5) for the Motor to be added to.
4. Press and hold the SET button on the Remote for 3 seconds and the channel buttons will stop blinking which indicates the remote is no longer in SETUP mode.

Set the Upper Limit (Vanes Closed)

1. Move the shade to the desired upper limit.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the (▲) button on the remote to save the upper limit.

Set the Lower Limit (Vanes Open)

1. Move the shade downwards, and stop with the vanes in the fully open position.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the (▼) button on the remote to save the vanes open position.

Set the Special Position (Vanes Closed)

1. Move the shade to the position where the vanes are closed and the shade is fully lowered.
2. Using a pin (not provided), press and hold the RESET button for 1 second. The center buttons will start blinking and the remote will now be in RESET mode.
3. Choose the channel which is paired to the shade. The selected channel will light up.
4. Press the SET button on the remote to save the vanes closed position.



Wake the Motor (New Installation)

The PerfectSheer motorised shades are sent from the factory asleep, to conserve the battery charge.

1. Press and hold the shade button on the motor head for 5 seconds.
 - i. The LED light will blink green, to indicate the motor is ready
 - ii. If the LED light blinks red, this indicates the motor is now off

Before following the instructions below, please check that the PerfectSheer motorised system is not already configured. The remote(s) and motor(s) are designed to be preprogrammed in the factory and should not require pairing or limit setting. Only shades of the same type should be programmed to the same channel as this will ensure optimal operation.

Add or Remove Shade from a Remote Channel

The instructions for adding or removing a shade from a channel on the remote is the same.

1. Press the shade button on the motor head 3 times. The LED will start blinking green, to indicate it is ready to receive a command.
2. Remove the battery cover on the remote, then press and hold the SET button for 3 seconds. The channel lights on the remote will be flashing.
3. Press the channel number (1-5) for the shade to be added or removed from. If the shade is added, it will shift once and if the shade is removed it will shift twice.
4. Press and hold the SET button, in the battery section of the remote, for 3 seconds.

Set or Clear the Upper Limit of a Shade

To avoid any unwanted setup or change to limits of other shades, we recommend that the shade be programmed on its own channel or that other shades are turned off until the limit setting is complete

1. Move the shade to the desired upper limit.
2. Remove the battery cover on the remote, then using a pin press hold the RESET button for 2 seconds. The channel lights on the remote will be flashing.

3. Press the channel number (1-5) of the shades for which the limit is to be set or cleared. To set the upper limit, simply press the OPEN button on the remote once. To clear the upper limit, press and hold the OPEN button for one second. If the limit has been set, the shade will shift once and if the limit is cleared, the shade will shift twice.

Set or Clear the Lower Limit (Vanes Open)

1. Move the shade to the desired lower limit where the vanes are fully open.
2. Remove the battery cover on the remote, then using a pin press and hold the reset button for 2 seconds. The channel lights on the remote will be flashing.
3. Press the channel number (1-5) of the shade for which the limit is to be set or cleared. To set the vanes closed position, simply press the CLOSE button on the remote once. To clear the vanes closed position, press and hold the CLOSE button for 1 second. If the limit has been set, the shade will shift once and if the limit is cleared, the shade will shift twice.

Set or Clear the Special Position (Vanes Closed)

1. Move the shade to the position where the vanes of the PerfectSheer are completely closed and the hem bar is resting at the bottom limit.
2. Remove the battery cover on the remote, then press and hold the SET button for 3 seconds. The channel lights on the remote will be flashing.
3. Press the channel number (1-5) of the shade for which the location is to be set or cleared.
4. To set the vanes closed position, simply press the SET button on the remote once. To clear the vanes closed position, press and hold the SET button for 1 second. If the location has been set, the shade will shift once and if the location is cleared the shade will shift twice.

